

### DOUBLE SIDED A SECTION

AA-51	AA-55	AA-75	AA-77	AA-80	AA-90
-------	-------	-------	-------	-------	-------

### DOUBLE SIDED B SECTION

BB-55	BB-75	BB-93	BB-112	BB-132	BB-162	BB-210
BB-60	BB-81	BB-94	BB-117	BB-136	BB-168	BB-270
BB-68	BB-85	BB-96	BB-118	BB-144	BB-173	
BB-70	BB-88	BB-97	BB-120	BB-150	BB-180	
BB-72	BB-90	BB-105	BB-123	BB-155	BB-190	
BB-73	BB-92	BB-110	BB-128	BB-158	BB-195	

### DOUBLE SIDED C SECTION

CC-81	CC-104	CC-120	CC-144	CC-164	CC-195	CC-240
CC-90	CC-105	CC-128	CC-158	CC-180	CC-210	CC-360
CC-96	CC-112	CC-140	CC-162			

## Fire Resistant Anti-Static (FRAS) V Belts

### A FRAS SECTION

A24-FRAS	A34-FRAS	A43-FRAS	A51-FRAS	A59-FRAS	A67-FRAS	A80-FRAS
A25-FRAS	A36-FRAS	A44-FRAS	A52-FRAS	A60-FRAS	A68-FRAS	A85-FRAS
A26-FRAS	A37-FRAS	A45-FRAS	A53-FRAS	A61-FRAS	A69-FRAS	A90-FRAS
A27-FRAS	A38-FRAS	A46-FRAS	A54-FRAS	A62-FRAS	A70-FRAS	
A30-FRAS	A39-FRAS	A47-FRAS	A55-FRAS	A63-FRAS	A72-FRAS	
A31-FRAS	A40-FRAS	A48-FRAS	A56-FRAS	A64-FRAS	A74-FRAS	
A32-FRAS	A41-FRAS	A49-FRAS	A57-FRAS	A65-FRAS	A75-FRAS	
A33-FRAS	A42-FRAS	A50-FRAS	A58-FRAS	A66-FRAS	A79-FRAS	

### B FRAS SECTION

B31-FRAS	B40-FRAS	B48-FRAS	B56-FRAS	B67-FRAS	B80-FRAS	B112-FRAS
B32-FRAS	B42-FRAS	B49-FRAS	B57-FRAS	B68-FRAS	B81-FRAS	B117-FRAS
B33-FRAS	B43-FRAS	B50-FRAS	B59-FRAS	B69-FRAS	B92-FRAS	B131-FRAS
B34-FRAS	B44-FRAS	B52-FRAS	B60-FRAS	B71-FRAS	B93-FRAS	B144-FRAS
B35-FRAS	B45-FRAS	B53-FRAS	B62-FRAS	B74-FRAS	B100-FRAS	
B36-FRAS	B46-FRAS	B54-FRAS	B63-FRAS	B75-FRAS	B103-FRAS	
B38-FRAS	B47-FRAS	B55-FRAS	B64-FRAS	B77-FRAS	B105-FRAS	

### C FRAS SECTION

C52-FRAS	C64-FRAS	C85-FRAS	C112-FRAS	C125-FRAS	C173-FRAS	C240-FRAS
C57-FRAS	C68-FRAS	C90-FRAS	C120-FRAS	C144-FRAS	C222-FRAS	C276-FRAS
C63-FRAS	C81-FRAS	C96-FRAS				